



F&F Filipowski sp.j.
Konstantynowska 79/81
95-200 Pabianice, Poland
Phone/fax (+48) 42 215 23 83, 227 09 71
e-mail: biuro@fif.com.pl

LE-01MB

Electric energy meter

1-phase

Bidirectional with network parameters analysis



User manual

v. 4.4 (170203)



www.fif.com.pl

CONTENTS

| | |
|--|-----------|
| 1. PURPOSE..... | 5 |
| 2. UNIT CHARACTERISTICS..... | 5 |
| 2.1. Measured value..... | 5 |
| 2.2. M-Bus protocole and communication port | 5 |
| 2.3. Pulse output..... | 5 |
| 3. OPERATOR PANEL | 6 |
| 3.1. LCD description..... | 6 |
| 3.2. Start-up screen | 6 |
| 3.3. Buttons features..... | 7 |
| 3.4. Meter indication..... | 8 |
| 4. SETUP..... | 10 |
| 4.1. Setup entry methods | 10 |
| 4.2. Number entry procedure | 10 |
| 4.3. Configuration menu | 11 |
| 4.3.1. M-Bus configuration..... | 11 |
| 4.3.2. Pulse output | 12 |
| 4.3.3. DIT - Demand Integration Time | 12 |
| 4.3.4. Automatic scrolling parameters indication..... | 12 |
| 4.3.5. Password changing | 12 |
| 5. TECHNICAL SPECIFICATION | 13 |
| 5.1. Measuring system | 13 |
| 5.2. Measured parameters | 13 |
| 5.3. Terminal | 13 |
| 5.4. Accuracy..... | 13 |
| 5.5. Pulse outputs..... | 14 |
| 5.6. M-Bus output | 14 |
| 5.7. Reference conditions of influence quantities | 14 |

| | |
|--|-----------|
| 5.8. Environment | 15 |
| 5.9. Structure..... | 15 |
| 5.10. Compliance and sealing | 15 |
| 6. DIMENSIONS..... | 16 |
| 7. WIRING DIAGRAM | 16 |
| 8. M-BUS PROTOCOLE | 17 |
| 8.1. Initialization Slave | 17 |
| 8.1.1. How to initialize a meter which you don't know the address | 17 |
| 8.1.2. Remove the secondary address matching symbol of all the meters on Bus | 17 |
| 8.1.3. How to initialize all meters on the bus line by using FF as broadcast address | 17 |
| 8.1.4. How to initialize a Slave with specific address | 17 |
| 8.2. How to set baud rate | 18 |
| 8.2.1. Point to point baud-rate setting command format | 18 |
| 8.2.2. How to use broadcast command to set baud rate | 18 |
| 8.3. How to set primary address | 19 |
| 8.3.1. How to set the address of a Slave to 01 | 19 |
| 8.3.2. How to use broadcast command to set primary address to 01 | 19 |
| 8.3.3. How to change address from 01 to 02 | 19 |
| 8.3.4. How to set primary address to 01 by using secondary address | 20 |
| 8.4. Set the complete identification of the Slave | 20 |
| 8.5. How to read out of energy information | 20 |
| 8.5.1. Use primary address 01 to read energy information | 20 |
| 8.5.2. How to read out a meter's energy information by using broadcast address 254 (FE) | 21 |
| 8.5.3. How to read out the meter's energy information by using secondary address | 21 |
| 8.6. Read out of instantaneous electrical information | 24 |
| 8.6.1. How to read instantaneous electrical information by using primary address | 24 |
| 8.6.2. How to use secondary address to read out the instantaneous electrical information | 24 |
| 8.7. How to read password..... | 30 |
| 8.7.1. Change to a new password | 30 |
| 8.8. How to reset all resettable energy data | 30 |
| 8.9. Set demand interval, slide time, display time, LED time | 30 |
| 8.10. Read demand interval, slide time, display time, LED time | 31 |

| | |
|--|-----------|
| 8.11. Read the measurement mode | 32 |
| 8.12. Set up the measurement mode | 32 |
| 8.13. Read the output mode of pulse 1 | 32 |
| 8.14. Set up the output mode of pulse 1 | 33 |
| 8.15. Read the constant of pulse 1..... | 33 |
| 8.16. Set up the constant of pulse 1..... | 33 |
| 9. MANUFACTURER'S WARRANTY | 34 |

1. Purpose

LE-01MB is a static (electronic), calibrated electricity meter of single-phase alternating current in direct system. It is used for reading and recording of imported electricity and parameters of the power supply with the ability of remote reading through a wired M-Bus network. Configuration of the meter is done through the configuration menu accessible from the front panel and through the communication port according to the software features of the M-Bus.

2. Unit characteristics

2.1. Measured value

The unit can measure and display:

- ✓ voltage
- ✓ frequency
- ✓ current
- ✓ power, maximum power demand and power factor
- ✓ active energy imported and exported
- ✓ reactive energy imported and exported

2.2. M-Bus protocole and communication port

Meter has a port with support for M-Bus protocol.

The M-Bus communication port allows you to combine the counters in the remote reading network.

2.3. Pulse output

The meter has two pulse outputs for mapping the counting of active and reactive energy.

Output 1 - terminals 6/5 - programmable, can be set to work for active or reactive energy and parameters: impulsion and pulse length.

Output 2 - terminals 4/5 - for active energy, impulsion is 1000 pulse/kWh.

3. Operator panel

3.1. LCD description




| No. | Description |
|-----|---|
| 1 | 7 digits used to display measured values or RTC |
| 2 | Total value |
| 3 | Tariff information |
| 4 | Energy: imported / exported |
| 5 | Maximum power or current demand |
| 6 | Pulse outputs 1 and pulse outputs 2 |
| 7 | Measurement units |
| 8 | PF - power factor |
| 9 | Power indicator |
| 10 | Communication indicator |
| 11 | Low battery warning |
| 12 | Lock symbol |

3.2. Start-up screen

After turning on the power, the meter performed a series of automatic indications:



All display segments light up, display check.



Software version (please check the real software version on the product as the final).



M-bus primary address



M-bus secondary address (High)



M-bus secondary address (Low)



Baud rate



Total kWh

3.3. Buttons features



- toggles between subsequent meter indications and meter configuration menu items
- entering digits 0-9
- long press to exit the settings menu and proceed to indications of the meter
- long press in the indications panel to enter the settings menu
- short press in the indications panel toggles on/off the Modbus communication lock for configuration parameters
- short press in the settings menu to switch to the next digit of the configured parameter
- long press in the settings menu to enter the setting of a given parameter and to accept it



3.4. Meter indication



Total active energy [kWh]



Import (input) active energy [kWh]



Export (output) active energy [kWh]



Total reactive energy [kVarh]



Import reactive energy [kVarh]



Export reactive energy [kVarh]



Max power demand



Voltage



Current



Active power [W]




Reactive power [Var]



Apparent power [VA]



Power factor



Frequency



Pulse 2 constant




M-bus primary address



M-bus secondary address (High)



M-bus secondary address (Low)




Baud rate


4. Setup

4.1. Setup entry methods

Some menu items, such as password, require a four-digit number entry while others, such as supply system, require selection from a number of menu options. After confirming the settings the meter confirms the adoption of a new parameter by displaying for a moment the word "good".



The error is signaled by the word "Err".



4.2. Number entry procedure

When setting up the unit, some screens require the entering of a number. In particular, on entry to the setting up section, a password must be entered. Digits are set individually, from left to right.

The procedure is as follows:

1. The current digit to be set flashes and is set using the button.
2. Press button, to confirm each digit setting.
3. After setting the last digit, press button, to exit the numer setting routine press button.


4.3. Configuration menu

To enter setup mode, pressing the  button for 2 seconds, until the password screen appears.



Setting up is password-protected so you must enter the correct password (default "1000") before processing

Press the  button for 2 seconds.



If an incorrect password is entered, the display will show:

PASS Err

To exit setting-up mode, press  button repeatedly until the measurement screen is restored.

4.3.1. M-Bus communication

Setting the communication port parameters.



Address: M-bus ID

Default: 001

Range: 001÷250



M-bus address extended (High)




M-bus address extended (Low)



Baud rate

Default value: 2400 kbps;

Values: 300, 600, 1200, 2400, 4800, 9600 kbps



Parity

Default: EVEN


Options: NONE, ODD, EVEN

4.3.2. Pulse output


Pulse output 1 configuration



Energy type
Default: kWh
Options: kWh / kWh / kVarh / Imp. kWh / Exp. kWh / Imp.kVarh / Exp.kVarh



Pulse constant
Default: 1000 pulse
Options: 1000 / 100 / 10 / 1 pulse



Pulse time
Default: 100 msec
Options: 200 / 100 / 60 msec

4.3.3. DIT - Demand Integration Time



Default: 15 minutes
Options: OFF (0) / 5 / 10 / 15 / 30 / 60 minutes

4.3.4. Automatic scrolling parameters indication



Default: 0 sec
Range: 0÷30 sec
Value 0 – No automatic scrolling

4.3.5. Password changing



Default: 1000
Range: 0000÷9999

5. Technical specification

5.1. Measuring system

1P2W – 1-phase 2-wire system (230V+N)

5.2. Measured parameters

| | |
|---|-----------------------------|
| Reference voltage: | 230V AC |
| Frequency: | 50 Hz |
| Base current Ib: | 5A |
| Maximum current I _{max} : | 100A |
| Minimum current measured I _{min} : | 0.25A |
| Starting current: | 0.4% of Ib/I _{ref} |
| Overload: | 30×I _{max} /10msec |
| Voltage measuring range: | 176÷276 V AC |
| AC surge voltage: | 4 KV per 1 minute |
| Pulse surge voltage: | 6 KV-1.2 uS |
| Power: | <2W/10VA |

5.3. Terminal

| | |
|----------------------|-------------------------------------|
| Measuring inputs | 16 mm ² screw terminals |
| Measuring outputs M- | 1.5 mm ² screw terminals |
| Bus port | 1.5 mm ² screw terminals |

5.4. Accuracy

| | |
|------------------------|-----------------------|
| Measurement class | B |
| Voltage | 0.5% of range maximum |
| Current | 0.5% of nominal |
| Frequency | 0.2% of mid-frequency |
| Power factor | 1% of unity (0.01) |
| Active power (W) | ±1% of range maximum |
| Reactive power (VAr) | ±1% of range maximum |
| Apparent power (VA) | ±1% of range maximum |
| Active energy (Wh) | ±1% 1 IEC 62053-21 |
| Reactive energy (VArh) | ±1% of range maximum |

5.5. Pulse outputs

Output type: OC (open collector); 27V DC/27 mA

Pulse:

Pulse output 1 is configurable: for kWh or kVArh.

Value set kWh/kVArh per 1 pulse:

1 = 1 kWh/kVArh

10 = 10 kWh/kVArh

100 = 100 kWh/kVArh

1000 = 1000 kWh/kVArh.

Pulse output 2 is non-configurable for kWh: 3200 pulse/kWh

Pulse width:

Output 1 - configurable: 200 / 100 / 60 msec

Output 2 - non-configurable: 200 msec

5.6. M-Bus output

Baud rate: 300, 600, 1200, 2400 (default), 4800, 9600 bps;

Parity: NONE - ODD / EVEN - default;

Stop bits: 1 / 2

Network address: 1÷250

5.7. Reference conditions of influence quantities

Influence quantities are variables that effect measurement errors to a minor degree.

Accuracy is verified under nominal value (within the specified tolerance) of these conditions.

| | |
|-----------------------------------|---------------------------------------|
| Ambient temperature | 23°C ±1°C |
| Input frequency | 50 or 60 Hz ±2% |
| Input waveform | sinusoidal (distortion factor <0.005) |
| Auxiliary supply voltage | nominal ±1% |
| Auxiliary supply frequency | nominal ±1% |
| Auxiliary supply waveform (if AC) | sinusoidal (distortion factor <0.05) |
| Magnetic field of external origin | terrestrial flux |

5.8. Environment

| | |
|------------------------|-----------------------------|
| Operating temperature | -25÷55°C |
| Storage temperature | -40÷70°C |
| Relative humidity | 0÷95%, without condensation |
| Installation category | CAT II |
| Mechanical environment | M1 |
| Degree of pollution | E2 |

5.9. Structure

| | |
|------------------|--------------------------------------|
| Mounting | on DIN rail |
| Cover | UI94 V-0 self-extinguishing material |
| Protection level | IP51 (inside) |

5.10. Compliance and sealing


2004/22/EC Directive

Certificate number: 0120/SGS0214


The meter is marked with individual serial numer allowing its explicit identification.

The marking is laser engraved and cannot be removed.

The meter has sealable input and output terminal cover to prevent any attempts to bypass the meter.




6. Dimensions



7. Wiring diagram

Single-phase 2-wire system



8. M-Bus protocole

8.1. Initialization Slave

Format:

| Start | C field | A field | Check sum | Stop |
|-------|---------|---------|-----------|------|
| 10 | 40 | XX | CS | 16 |

XX=1 to FF

The address field serves to address the recipient in the calling direction, and to identify the sender of information in the receiving direction. The size of this field is one byte, and can therefore take values from 0 to 255.. The addresses 1 to 250 can be allocated to the individual slaves, up to a maximum of 250. Unconfigured slaves are given the address 0 at manufacture, and as a rule are allocated one of these addresses when connected to the M-Bus. The addresses 254 (FE) and 255 (FF) are used to transmit information to all participants (Broadcast). With address 255 none of the slaves reply, and with address 254 all slaves reply with their own addresses. The latter case naturally results in collisions when two or more slaves are connected, and should only be used for test purposes. The address 253 (FD) indicates that the addressing has been performed in the Network Layer instead of Data Link Layer, the FD used when using the second level address. The remaining addresses 251 and 252 have been kept for future applications.

8.1.1. How to initialize a meter which you don't know the address

Master to Slave: 10 40 FE 3E 16

Slave to Master: E5 (success)

8.1.2. Remove the secondary address matching symbol of all the meters on Bus

Master to Slave: 10 40 FD 3D 16

Slave: **No answer**

8.1.3. How to initialize all meters on the bus line by using FF as broadcast address

Master to Slave: 10 40 FF 3F 16

Slave: **No answer**

8.1.4. How to initialize a Slave with specific address

Example: address 01

Master to Slave: 10 40 01 41 16

Slave to Master: E5

8.2. How to set baud rate

8.2.1. Point to point baud-rate setting command format (Control frame)

| Start | L field | L field | Start | C field | A field | CI field | Check sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----------|------|
| 68H | 03 | 03 | 68H | 53/73 | FE | B8-BD | CS | 16 |

- L field - Byte length
 C field - Control field, function field
 A field - Address field
 CI field - Control information field
 Check sum - The Check sum is calculated from the arithmetical sum of the data mentioned above, without taking carry digits into account.

B8-----300
 B9-----600
 BA-----1200
 BB-----2400
 BC-----4800
 BD-----9600

Example:

(1) How to change baud rate to 2400 bps.

Master to Slave: 68 03 03 68 53 FE BB 0C 16 E5

Slave to Master:

(2) How to change baud rate to 9600 bps.

Master to Slave: 68 03 03 68 53 FE BD 0C 16

Slave to Master: E5

8.2.2. How to use broadcast command to set baud rate

Format:

| Start | L field | L field | Start | C field | A field | CI field | Check sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----------|------|
| 68H | 03 | 03 | 68H | 53/73 | FF | B8-BD | CS | 16 |

Slave to Master: No answer

B8-----300
 B9-----600
 BA-----1200
 BB-----2400
 BC-----4800
 BD-----9600

Example:

Change all the meter's baud rate to 2400 bps.

Master to Slave: 68 03 03 68 53 **FF** BB 0D 16

Slave to Master: No answer

8.3. How to set primary address

8.3.1. How to set the address of a Slave to 01

Format:

| Start | L field | L field | Start | C field | A field | Cl field | DIF | VIF | Address data | Check sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----|-----|--------------|-----------|------|
| 68H | 06 | 06 | 68H | 53/73 | FE | 51 | 01 | 7A | XX | CS | 16 |

Example:

Master to Slave: 68 06 06 68 53 FE 51 01 7A **01** 1E 16

Slave to Master: E5

8.3.2. How to use broadcast command to set primary address to 01

Format:

| Start | L field | L field | Start | C field | A field | Cl field | DIF | VIF | Address data | Check sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----|-----|--------------|-----------|------|
| 68H | 06 | 06 | 68H | 53/73 | FF | 51 | 01 | 7A | XX | CS | 16 |

Example:

Master to Slave: 68 06 06 68 53 **FF** 51 01 7A **01** 1F 16

Slave: No answer

8.3.3. How to change address from 01 to 02

Format:

| Start | L field | L field | Start | C field | A field | Cl field | DIF | VIF | Address data | Check sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----|-----|--------------|-----------|------|
| 68H | 06 | 06 | 68H | 53/73 | XX | 51 | 01 | 7A | YY | CS | 16 |

XX - current primary address

YY - new primary address

Master to Slave: 68 06 06 68 73 **01** 51 01 7A **02** 42 16

Slave to Master: E5

8.3.4. How to set primary address to 01 by using secondary address

Example: secondary address: 12345678

Step 1

Initialize the Slave

Master to Slave: 10 40 FE 3E 16

Slave to Master: E5

Step 2

Check the secondary address.

After receiving the command, the Slave will check if the secondary address in the command is same with its secondary address or not.

Master to Slave: 68 0B 68 73 FD 52 **78 56 34 12** FF FF FF FF D2 16

FD --- the primary address used when you use secondary address to read data. **78 56 34 12** - the meter's secondary address is 12 34 56 78

Master to Slave: E5 (success)

Step 3

Change the primary address to 01

Master to Slave: 68 06 06 68 73 FD 51 01 7A **01** 3D

01 --- new primary address

Slave to Master: E5

8.4. Set the complete identification of the Slave

(ID=12345678, Man=4024h (PAD), Gen=1, Med=02 (energy))

| Start | L field | L field | Start | C field | A field | Cl field | DIF | VIF |
|-------|---------|---------|-------|---------|---------|----------|-----|-----|
| 68H | 0D | 0D | 68H | 53/73 | FE | 51 | 07 | 79 |

| Identification No | Manufacturer ID | Generation | Medium | Check sum | Stop |
|-------------------|-----------------|------------|--------|-----------|------|
| 4 bytes | 2 bytes | 1 byte | 1 byte | CS | 16 |

Master to Slave: 68 0D 0D 68 53 **FE** 51 07 79 78 56 34 12 24 40 01 02 9D 16

Slave to Master: E5

8.5. How to read out of energy information

8.5.1. Use primary address 01 to read energy information

Format:

Master to Slave: 10 7B/5B adr CS 16

Slave to Master: Variable data structure

Example: 10 7B 01 7C 16

8.5.2. How to read out a meter's energy information by using broadcast address 254 (FE)

Master to Slave: 10 7B/5B FE CS 16
Slave to Master: Variable data structure
Example: 10 5B FE 59 16

8.5.3. How to read out the meter's energy information by using secondary address

Example:
Secondary address: 12 34 56 78

Step 1

Initialize the Slave

Master to Slave: 10 40 FF 3F 16
Slave to Master: No answer

Step 2

Check the secondary address.

After receiving the command, the slave will check if the secondary address in the command is same with its secondary address or not.

Master to Slave: 68 0B 68 73 FD 52 78 56 34 12 FF FF FF D2 16 E5
Slave to Master:

Step 3

Read the energy information

Master to Slave: 10 7B **FD** 78 16
Slave to Master: DIF===== Coding of the Data Information Field
VIF===== Codes for Value Information Field

| Bytes | Parameters | Data structure | Notice |
|-------|---|----------------|------------------------------------|
| 4 | Header telegram | 68 5D 5D 68 | Header of RSP_UD telegram |
| 3 | | 08 A 72 | C field=08 address A CI field 72 |
| 4 | | 78 65 34 21 | Identification number = 12345678 |
| 2 | | 24 40 | Manufacturer ID 4024 |
| 1 | | 01 | Generation 1 |
| 1 | | 02 | Energy meter |
| 1 | | 55 | ACCESS NO |
| 1 | | 00 | STATUS |
| 2 | | 00 00 | Signature |
| 6 | Current total active energy | 0C | DIF: 8 digit BCD, current value |
| | | 04 | VIF: 10 W (0.01 kW) |
| | | 78 56 34 12 | 123456.78 kWh |
| 7 | Current import active energy | 0C | DIF: 8 digit BCDFIE, current value |
| | | 04 | VIF: 10 W (0.01 kW) |
| | | 78 56 34 12 | 123456.78 kWh |
| 7 | Current export active energy | 0C | DIF: 8 digit BCDFIE, current value |
| | | 04 | VIF: 10 W (0.01 kW) |
| | | 78 56 34 12 | 123456.78 kWh |
| 6 | Current resettable total active energy | 0C | DIF: 8 digit BCD, current value |
| | | 04 | VIF: 10 W (0.01 kW) |
| | | 78 56 34 12 | 123456.78 kWh |
| 7 | Current resettable import active energy | 0C | DIF: 8 digit BCDFIE, current value |
| | | 04 | VIF: 10 W (0.01 kW) |
| | | 78 56 34 12 | 123456.78 kWh |
| 7 | Current resettable export active energy | 0C | DIF: 8 digit BCDFIE, current value |
| | | 04 | VIF: 10 W (0.01 kW) |
| | | 78 56 34 12 | 123456.78 kWh |

| Bytes | Parameters | Data structure | Notice |
|-------|---|----------------|------------------------------------|
| 7 | Current total reactive energy | 0C | DIF: 8 digit BCD, current value |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 78 56 34 12 | 123456.78 kVarh |
| 8 | Current import reactive energy | 0C | DIF: 8 digit BCDFIE, current value |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 78 56 34 12 | 123456.78 kVarh |
| 8 | Current export reactive energy | 8C | DIF: 8 digit BCDFIE, current value |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 78 56 34 12 | 123456.78 kVarh |
| 7 | Current total resettable reactive energy | 0C | DIF: 8 digit BCD, current value |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 78 56 34 12 | 123456.78 kVarh |
| 8 | Current resettable import reactive energy | 0C | DIF: 8 digit BCDFIE, current value |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 78 56 34 12 | 123456.78 kVar |
| 8 | Current resettable export reactive energy | 0C | DIF: 8 digit BCDFIE, current value |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 78 56 34 12 | 123456.78 kVar |
| 1 | CHECK SUM | CS | |
| 1 | End | 16 | |

8.6. Read out of instantaneous electrical information

The instantaneous electrical information includes:

V, I, P , Q, S, PF, Hz ect. MD

8.6.1. How to read instantaneous electrical information by using primary address

| Start | L field | L field | Start | C field | A field | Cl field | Check sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----------|------|
| 68H | 3 | 3 | 68 | 53/73 | XX | B1 | CS | 16 |

Master to Slave: 68 03 03 68 53 **XX** B1 05 16

Slave to Master: Variable data structure (instantaneous electrical information)

If the primary address is 01, then XX=01

8.6.2. How to use secondary address to read out the instantaneous electrical information

Step 1

Initialize the Slave

Master to Slave: 10 40 FF 3F 16

Slave to Master: No answer

Step 2

Check the secondary address.

After receiving the command, the slave will check if the secondary address in the command is same with its secondary address or not.

Master to Slave: 68 0B 68 73 FD 52 78 56 34 12 FF FF FF FF D2 16 E5

Slave to Master:

Step 3

Use secondary address to read out the instantaneous electrical information.

Master to Slave: 68 03 03 68 53 **FD** B1 01 16

Slave to Master: Variable data structure

| Bytes | Parameters | Data structure | Notice |
|-------|-----------------|----------------|-----------------------------------|
| 4 | Header telegram | 68 90 90 68 | Header of RSP_UD telegram |
| 3 | | 08 A 72 | C field =08 address A CI field 72 |
| 4 | | 78 65 34 21 | Identification number = 12345678 |
| 2 | | 24 40 | Manufacturer ID 4024 |
| 1 | | 01 | Generation 1 |
| 1 | | 02 | Energy meter |
| 1 | | 55 | ACCESS NO |
| 1 | | 00 | STATUS |
| 2 | | 00 00 | Signature |
| 6 | L1 voltage | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 47 | VIFE: 0.01 V |
| | | 56 34 12 | 1234.56 V |
| 6 | L2 voltage | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 47 | VIFE: 0.01 V |
| | | 56 34 12 | 1234.56 V |
| 6 | L3 voltage | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 47 | VIFE: 0.01 V |
| | | 56 34 12 | 1234.56 V |
| 6 | L1 - L2 voltage | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 47 | VIFE: 0.01 V |
| | | 56 34 12 | 1234.56 V |

| Bytes | Parameters | Data structure | Notice |
|-------|--------------------|----------------|---------------------------|
| 6 | L2 - L3 voltage | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 47 | VIFE: 0.01 V |
| | | 56 34 12 | 1234.56 V |
| 6 | L2 - L3 voltage | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 47 | VIFE: 0.01 V |
| | | 56 34 12 | 1234.56 V |
| 6 | L1 current | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 59 | VIFE: 1 mA (xxx.xxx A) |
| | | 56 34 12 | 123456 mA (123.456 A)) |
| 6 | L2 current | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 59 | VIFE: 1 mA (xxx.xxx A) |
| | | 56 34 12 | 123456 mA (123.456 A) |
| 6 | L3 current | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 59 | VIFE: 1 mA (xxx.xxx A) |
| | | 56 34 12 | 123456 mA (123.456 A) |
| 6 | N current | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 59 | VIFE: 1 mA (xxx.xxx A) |
| | | 56 34 12 | 123456mA (123.456A) |
| 5 | Total active power | 0B | DIF: 6 digit BCD |
| | | 2A | VIF: 0.1 W (xx.xxxx kW)) |
| | | 56 34 12 | 12345.6 W (12.3456 kW) |

| Bytes | Parameters | Data structure | Notice |
|-------|----------------------|----------------|------------------------------|
| 5 | L1 active power | 0B | DIF: 6 digit BCD |
| | | 2A | VIF: 0.1 W (xx.xxxx kW)) |
| | | 56 34 12 | 12345.6 W (12.3456 kW) |
| 5 | L2 active power | 0B | DIF: 6 digit BCD |
| | | 2A | VIF: 0.1 W (xx.xxxx kW)) |
| | | 56 34 12 | 12345.6 W (12.3456 kW) |
| 5 | L3 active power | 0B | DIF: 6 digit BCD |
| | | 2A | VIF: 0.1 W (xx.xxxx kW)) |
| | | 56 34 12 | 12345.6 W (12.3456 kW) |
| 6 | Total reactive power | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 56 34 12 | 12345.6 W (12.3456 kW) |
| 6 | L1 reactive power | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 56 34 12 | 12345.6 W (12.3456 kW) |
| 6 | L2 reactive power | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 56 34 12 | 12345.6 W (12.3456 kW) |
| 6 | L3 reactive power | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 56 34 12 | 12345.6 W (12.3456 kW) |

| Bytes | Parameters | Data structure | Notice |
|-------|----------------------|----------------|------------------------------|
| 5 | L1 active power | 0B | DIF: 6 digit BCD |
| | | 2A | VIF: 0.1 W (xx.xxxx kW) |
| | | 56 34 12 | 12345.6 W (12.3456 kW) |
| 5 | L2 active power | 0B | DIF: 6 digit BCD |
| | | 2A | VIF: 0.1 W (xx.xxxx kW) |
| | | 56 34 12 | 12345.6 W (12.3456 kW) |
| 5 | L3 active power | 0B | DIF: 6 digit BCD |
| | | 2A | VIF: 0.1 W (xx.xxxx kW) |
| | | 56 34 12 | 12345.6 W (12.3456 kW) |
| 6 | Total reactive power | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 56 34 12 | 12345.6 W (12.3456 kW) |
| 6 | L1 reactive power | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 56 34 12 | 12345.6 W (12.3456 kW) |
| 6 | L2 reactive power | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 56 34 12 | 12345.6 W (12.3456 kW) |
| 6 | L3 reactive power | 0B | DIF: 6 digit BCD |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 56 34 12 | 12345.6 W (12.3456 kW) |

| Bytes | Parameters | Data structure | Notice |
|-------|--------------------|----------------|------------------------------|
| 5 | Total power factor | 0a | DIF: 4 digit BCD |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 00 05 | 0.500 |
| 5 | A power factor | 0A | DIF: 4 digit BCD |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 00 05 | 0.500 |
| 5 | B power factor | 0A | DIF: 4 digit BCD |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 00 05 | 0.500 |
| 5 | C power factor | 0A | DIF: 4 digit BCD |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 00 05 | 0.500 |
| 5 | Frequency | 0A | DIF: 4 digit BCD |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 00 50 | 50.00 Hz |
| 1 | End | CS | |
| 1 | | 16 | |

8.7. How to read password

| Start | L field | L field | Start | C field | A field | Cl field | Check sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----------|------|
| 68 | 3 | 3 | 68 | 11 | addr | 03 | CS | 16 |

Master to Slave: 68 03 03 68 11 address 03 CS 16

Slave to Master: 68 05 05 68 11 address 03 passwordH passwordL CS 16

8.7.1. Change to a new password

| Start | L field | L field | Start | C field | A field | Cl field | Data | Check sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----------------------|-----------|------|
| 68 | 5 | 5 | 68 | 11 | addr | 04 | password H password L | CS | 16 |

Master to Slave: 68 05 05 68 11 address 04 passwordH passwordL CS 16

Slave to Master: E5

8.8. How to reset all resettable energy data

| Start | L field | L field | Start | C field | A field | Cl field | Check sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----------|------|
| 68 | 3 | 3 | 68 | 11 | addr | 0D | CS | 16 |

Example: addr: 01

Master to Slave: 68 03 03 68 11 01 0D 1F 16

Slave to Master: E5

8.9. Set demand interval, slide time, display time, LED time

Send: 68 09 09 68 53 FE 51 30 01 60 01 05 06 3F 16

| Start | L field | L field | Start | C field | A field | Cl field | DIF | VIF | Check sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----|-----|-----------|------|
| 68H | 09 | 09 | 68H | 53/73 | FE | 51 | 30 | 01 | CS | 16 |

Example: (Meter address is 01)

Master to Slave: 68 09 09 68 53 FE 51 30 01 60 01 05 06 3F 16

Slave to Master: E5

Demand interval, slide time, display time, LED time

Display time=0: the display not scroll automatically.

LED time=0: Backlight always on min-min-s-min 4 Bytes

8.10. Read demand interval, slide time, display time, LED time

| Start | L field | L field | Start | C field | A field | CI field | DIF | VIF | Check sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----|-----|-----------|------|
| 68H | 05 | 05 | 68H | 53/73 | FE | 51 | 30 | 81 | CS | 16 |

Example: (Meter address is 01)

Master to Slave: 68 05 05 68 53 FE 51 30 81 53 16

Slave to Master: E5

| Bytes | Parameters | Data structure | Notice |
|-------|---|----------------|---|
| 4 | Header telegram | 68 16 16 68 | Header of RSP_UD telegram |
| 3 | | 08 A 72 | C field =08 address A CI field72 |
| 4 | | 78 65 34 21 | Identification number = 12345678 |
| 2 | | 24 40 | Manufacturer ID 4024 |
| 1 | | 01 | Generation 1 |
| 1 | | 02 | Energy meter |
| 1 | | 55 | ACCESS NO |
| 1 | | 00 | STATUS |
| 2 | | 00 00 | Signature |
| 7 | Demand interval, slide time, display time, LED time | 0A | DIF: 30 digit BCD |
| | | FD | VIF: FD |
| | | 3A | VIFE: dimensionless / no VIF |
| | | 15010610 | Demand interval: 15 min. Slide time: 01 min. Display time: 06 sec LED time: 10 sec |
| 1 | Check sum | CS | |
| 1 | Koniec | 16 | |

8.11. Read the measurement mode

| Start | L field | L field | Start | C field | A field | Cl field | Data | Check sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|----------|-----------|------|
| 68 | 03 | 03 | 68 | 11 | addr | 0A | 01/02/03 | CS | 16 |

Example: (Meter address is 01)

Master to Slave: 68 03 03 68 11 01 09 1B 16

Slave to Master: 68 04 04 68 11 01 09 01 1C 16

The red-lighted 01 represents the measurement mode:

01: means active energy

02: means active energy + reactive energy

03: means active energy - reactive energy

8.12. Set up the measurement mode

| Start | L field | L field | Start | C field | A field | Cl field | Data | Check sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|----------|-----------|------|
| 68 | 04 | 04 | 68 | 11 | addr | 0A | 01/02/03 | CS | 16 |

Example: (Meter address is 01)

Master to Slave: 68 04 04 68 11 01 0A 01 1C 16

Slave to Master: E5

The red-lighted 01 represents the measurement mode:

01: means active energy

02: means active energy + reactive energy

03: means active energy - reactive energy

8.13. Read the output mode of pulse 1

| Start | L field | L field | Start | C field | A field | Cl field | Check sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----------|------|
| 68 | 03 | 03 | 68 | 11 | addr | 10 | CS | 16 |

Example: (Meter address is 01)

Master to Slave: 68 03 03 68 11 01 10 22 16

Slave to Master: 68 04 04 68 11 01 10 01 23 16

The red-lighted 01 represents the output mode of pulse 1:

01: Import active energy

02: Import + export active energy

04: Export active energy (default)

05: Import reactive energy

06: Import + export reactive energy

08: Export reactive energy

8.14. Set up the output mode of pulse 1

| Start | L field | L field | Start | C field | A field | CI field | Data | Check sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-------------------|-----------|------|
| 68 | 08 | 08 | 68 | 11 | addr | 11 | 01/02/04/05/06/08 | CS | 16 |

Example: (Meter address is 01)

Master to Slave: 68 04 04 68 11 01 11 **01** 24 16

Slave to Master: E5

The red-lighted **01** represents the output mode of Pulse1:

- 01: Import active energy
- 02: Import + export active energy
- 04: Export active energy (default)
- 05: Import reactive energy
- 06: Import + export reactive energy
- 08: Export reactive energy

8.15. Read the constant of pulse 1

| Start | L field | L field | Start | C field | A field | CI field | Check sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-----------|------|
| 68 | 03 | 03 | 68 | 11 | addr | 12 | CS | 16 |

Example: (Meter address is 01)

Master to Slave: 68 03 03 68 11 01 12 24 16

Slave to Master: 68 04 04 68 11 01 10 **00** 22 16

The red-lighted **00** represents the constant of pulse 1:

- 00: 0.0025 kWh (kvarh)/pulse (default)
- 01: 0.01 kWh (kVarh)/pulse
- 02: 0.1 kWh (kVarh)/pulse
- 03: 1 kWh (kVarh)/pulse
- 04: 10 kWh (kVarh)/pulse
- 05: 100 kWh (kVarh)/pulse

8.16. Set up the constant of pulse 1

| Start | L field | L field | Start | C field | A field | CI field | Data | Check sum | Stop |
|-------|---------|---------|-------|---------|---------|----------|-------------------|-----------|------|
| 68 | 08 | 08 | 68 | 11 | addr | 11 | 00/01/02/03/04/05 | CS | 16 |

Example: (Meter address is 01)

Master to Slave: 68 04 04 68 11 01 13 **00** 25 16

Slave to Master: E5

The red-lighted **00** represents the constant of pulse 1:

- 00: 0.0025 kWh (kVarh)/pulse (default)
- 01: 0.01 kWh (kVarh)/pulse

- 02: 0.1 kWh (kVarh)/pulse
- 03: 1 kWh (kVarh)/pulse
- 04: 10 kWh (kVarh)/pulse
- 05: 100 kWh (kVarh)/pulse

9. Manufacturer's warranty

1. The product is covered by 24 month warranty from the date of purchase.
2. The warranty is valid only with a proof of purchase.
3. The notification of the complaint must be made at the place of purchase or directly at the manufacturer:
(phone: +48 (42) 227 09 71; e-mail: reklamacje@fif.com.pl)
4. During the warranty period in the case of a justified complaint the manufacturer commits in accordance with the provisions of the consumer rights to repair the product, replace it with a new one or refund.
5. The complaint will be processed within 14 days from the date of delivering the product to the service point.
6. Warranty does not cover:
 - mechanical and chemical damages;
 - damages resulting from improper use or from the use inconsistent with the user manual;
 - damages incurred after the sale as a result of accidents or other events for which nor the producer, nor the place of sale are responsible, for example damages in transit, etc.
7. Warranty does not cover actions that user should perform in accordance with the user manual, for example installing multi-meter, building electrical installation, installing other required electrical protection, checking, etc.

Warning!

Do not make any changes in the device by yourself. This may cause damage or improper operation of the device, which can lead to damage to the controlled device and may pose a danger to the operators. In such cases, the manufacturer is not liable for consequential events and may refuse the guarantee in case of complaint.