



ul. Konstytucyjna 79/81
95-200 Pabianice
tel/fax 48 42 2270971 POLAND
e-mail: fif@fif.com.pl

DMV-1
True RMS
DIGITAL VOLTAGE INDICATOR
one-phase



5 19 0 8 3 1 2 1 5 9 1 9 6 2

www.fif.com.pl


F&F products are covered by an 24 months warranty from date of purchase

PURPOSE

Voltage indicator is devised to continually measure the value of the voltage in a circuits of one-phases.

FUNCTIONING

Indicator DMV-1 with measurement system True RMS display real value of effective voltage in phase.




ASSEMBLY

1. Take OFF the power.
2. Connect directly indicator to system with wiring diagram.
3. Take On the power.

TECHNICAL DATA

supply	100+300V AC
supply frequency	45+55Hz
range of reports	100+300V
precision	0,5%
display	segment LED 10×6mm
power consumption	4W
working temperature	-25+50°C
dimensions	3 modules (52,5mm)
fixing	on rail TH-35

WIRING DIAGRAM



A090721