

F&F Filipowski L.P. Konstantynowska 79/81, 95-200 Pabianice, POLAND phone/fax (+48 42) 215 23 83 / (+48 42) 227 09 71 www.fif.com.pl; e-mail; biuro@fif.com.pl

I F-01M Electric energy meter, 1-phase



Do not dispose of this device in the trash along with other waste!

According to the Law on Waste, electro coming from households free of charge and can give any amount to up to that end point of collection, as well as to store the occasion of the purchase of new equipment (in accordance with the principle of old-for-new, regardless of brand). Electro thrown in the trash or abandoned in nature, pose a threat to the environment and human health



Compliance

MID Directive Certificate

2014/32/EU 0120/SGS0159

Purpose

The LE-01M is a static (electronic) calibrated electricity meter of single-phase alternating current in a direct system. It is used for reading and recording of consumed electric energy and mains parameters with remote readout via a wired RS-485 network.

Functioning

The LE-01M under the influence of current flow and applied voltage makes precise measurement of the amount of consumed electricity. Energy consumption is indicated by a flashing LED (1600 pulse/kWh) and its value is determined by the LCD display. Decimals represent hundredths of kWh (0.01 kWh = 10 Wh).

Communication with the rate of working as slave devices is carried out according to the standard Modbus RTU via RS-485. Read register values after conversion kWh give a result consistent with the indications on the display indicator.

Each of the indicators is identified by a unique address transmitted by the user.

Measured value

Active energy consumed

AE+ [kWh]

Pulse output

The meter is equipped with pulse output open collector (OC type). This allows you to connect another pulse device (SO) that reads pulses generated by the meter.

No additional connected equipment is required for proper operation of the meter

The length of the pulse depends on the load on the meter:

| 5÷40 A: 80 msec | 65 A: 80 msec | 90 A: 38 msec |
|-----------------|---------------|----------------|
| 45 A: 75 msec | 70 A: 48 msec | 95 A: 36 msec |
| 50 A: 68 msec | 75 A: 46 msec | 100 A: 34 msec |
| 55 A: 62 msec | 80 A: 42 msec | |
| 60 A: 57 msec | 85 A: 40 msec | |

Meter address

Change of meter address is done via the RS-485 port using the Modbus RTU protocol command to set the desired value in the meter register. The default meter address: 1.

Meter number

The meter is marked with individual serial number allowing its unambiguous identification. The marking is laser engraved and cannot be removed).



Sealing

The meter has sealable input and output terminal covers to prevent any attempts to bypass the meter.



Wiring diagram



- 1 LIN phase wire
- 2 LOUT phase wire
- 3 NIN neutral wire
- 4 Nout neutral wire

- 5 pulse output (-)
- 6 pulse output (+)
- 7 RS-485 output (B)
- 8 RS-485 output (A)

Modbus RTU protocol parameters

Communication parameters

| Protocol | Modbus RTU |
|--------------------------------------|---|
| Operation mode | Slave |
| Port settings | Baud rate: 9600 bps Parity: NONE Stop bits: 1 |
| Modbus address (factory settings) | <u>1</u> ÷245 |

| Measurement | registers |
|-------------|-----------|
|-------------|-----------|

| address | description | com- mand | type | atr |
|---------|--------------------|--------------|------|-----|
| 0 | Active energy (R0) | 03 | int | R |
| 1 | Active energy (R1) | 03 | int | R |
| 2 | Active energy (R2) | 03 | int | R |
| 6 | Meter address | 06 | int | W |

Legend:

R - read, W - write.

Register values are stored as integers.

To get a reading, the three received registers values should be transform algebraically in accordance with the following formula:

(R0 × 256² + R1 × 256 + R2) / 100,

where:

- R0 register number 0;
- R1 register number 1;
- R2 register number 2

Dimensions



LE Config service programm

Program for test reading of the counted energy value and for basic settings of the meter parameters.

Available at <u>www.fif.com.pl</u> (on the device's subpage).

For communication of the meter with the computer, the USB CN-USB-485 converter or any RS-485/USB standard is required.

Technical data

| installation | 2-wire |
|------------------------------------|-----------------|
| rated voltage | 230 V AC |
| minimum measured current | 0.04 A |
| base current | 5 A |
| maximum current | 80 A |
| voltage measuring range | 160÷265 V |
| measurement accuracy (EN50470-1/3) | class B |
| rated frequency | 50 Hz |
| insulation protection class | II |
| housing | PC+ABS material |
| own power consumption | <10 VA; <2 W |
| indication range | 0÷99999.99 kWh |
| constant | 1600 pulses/kWh |
| read-out signalling | red LED |
| communication | |
| port | RS-485 |
| communication protocol | Modbus RTU |
| transmission parameters | 9600 bps |
| parity | NONE |
| stop bits | 1 |
| pulse output | |
| type | open collector |
| maximum voltage | 27 V DC |
| maximum current | 27 mA |
| pulse constant | 1600 pulses/kWh |
| pulse time | 34÷80 ms* |

^{*} depends on the current consumption

working temperature terminal dimensions mounting ingress protection -25÷55°C 25 mm² screw terminals 4.5 modules (75 mm) on TH-35 rail IP20

Warranty

F&F products are covered by a 24-month warranty from the date of purchase. The warranty is only valid with proof of purchase. Contact your dealer or contact us directly.

CE declaration

F&F Filipowski L.P. declares that the device is in conformity with the essential requirements of the Low Voltage Directive (LVD) 2014/35/EU and the Electromagnetic Compatibility (EMC) Directive 2014/30/UE.

The CE and MID Declaration of Conformity, along with the references to the standards in relation to which conformity is declared, can be found <u>www.fif.com.pl</u> on the product subpage.