



#### Purpose

The WB-2 three-position switch is used to control devices from the switchboard. It allows you to alternately trigger one of the two outputs.

#### Mounting

- 1. Disconnect the power supply.
- 2. Install the switch on the rail in the distribution board.
- 3. Connect the power wires according to the diagram.
- 4. Check the correct connection.
- 5. Connect the power supply.
- 6. Check the correct operation of the system.





# **Description of terminals**

1, 3, 10, 12	COM input
4, 6	output 1
7, 9	output 2

## Technical data

contact maximum operating voltage maximum load current (AC-1)

contact resistance contact life terminal tightening torque working temperature dimensions

mounting ingress protection ON-OFF-ON 250 V AC 15 A (250 V AC) 20 A (125 V AC) max 35 mΩ 10.000 cycles 2.5 mm² screw terminals 0.4 Nm -25÷50°C 1 module (18 mm)

> on TH-35 rail IP20

## Warranty

F&F products are covered by a 24-month warranty from the date of purchase. The warranty is only valid with proof of purchase. Contact your dealer or contact us directly.

### **CE declaration**

F&F Filipowski sp. j. declares that the device is in conformity with the essential requirements of The Low Voltage Directive (LVD) 2014/35/EU and the Electromagnetic Compatibility (EMC) Directive 2014/30/UE.

The CE Declaration of Conformity, along with the references to the standards in relation to which conformity is declared, can be found <u>www.fif.com.pl</u> on the product subpage.